

## Additional instructions for Kit 2



all information from right and left are always given in the direction of travel



For models suitable for this kit, proceed as follows to attach the rear AXfix in the direction of travel as follows:

1. Insert the AXfix through the wheel axle from the left.
2. Insert the single-sided swing arm adapter into the hollow axle from the right.
3. Then screw the individual cone with handle on the right side tightly by hand.



- do not use any tools!
- make sure that the cones are centered!



Picture in direction of travel left



Image in direction of travel right