

Additional instructions for Kit 4; 5; 8; 23, 25 and 28



all information from right and left are always given in the direction of travel

To attach the front AXfix in the direction of travel, proceed as follows:

1. Ensure the vehicle is stable. 2. Remove the original axle bolt on the front axle. (Image 1)
3. Replace it with the hollow screw included in the kit. (Image 2)
4. Tighten this banjo bolt according to the motorcycle manufacturer's recommendations.



- Use a torque wrench and the specified torque or have the screw replaced in a specialist workshop!

You only need to perform steps 1 to 4 once. The hollow screw can then remain permanently on the vehicle.

5. Insert the AXfix through the hollow axle and proceed as described in the user manual specified. (Image 3)

Example images KTM 1290 Adventure – front left



Image 1



Image 2



Image 3