



Additional instructions for Kit 7



all information from right and left are always given in the direction of travel

For models suitable for this kit, proceed as follows to attach the AXfix:

Rear in direction of travel:

1. Insert the larger adapter (aluminum) into the single-sided swing arm from the right.
2. Insert the AXfix through the hollow axle from the left.
3. Then screw the single cone with handle on the left side tightly by hand.



- do not use any tools!

Make sure the cones are centered!

Front in direction of travel:

4. Insert the AXfix through the hollow axle from the right.
5. Place the plastic disc onto the AXfix from the left (with the recess facing outwards).
6. Then screw the single cone with handle on the left side tightly by hand.



- do not use any tools!

- make sure that the cones are centered!



Picture in direction of travel rear left



Picture in direction of travel rear right



Picture in direction of travel front left



Picture in direction of travel front right