

Additional instructions for Kit 9



all information from right and left are always given in the direction of travel



For models suitable for this kit, proceed as follows to attach the front AXfix in the direction of travel as follows:

1. Push the AXfix through the front hollow axle from the right.
2. Place the plastic disc onto the AXfix from the left (with the recess facing outwards).
3. Then screw the single cone with handle on the left side tightly by hand.



- do not use any tools!
- make sure that the cones are centered!



Picture in direction of travel left



Image in direction of travel right