

## How to measure your axle's



If your motorcycle is not listed on the [fitment list](#), Follow these simple steps to find our your axle measurements which will help us to locate the correct AXfix kit for your motorcycle.

### **Step 1:**

Using digital vernier calipers, measure the internal opening gap on both the left and right side of the front and rear axles.



## **Step 2:**

Using a tape measure, measure the length of your spindle or opening for a single sided swinging arm. This can be done by removing the spindle completely, placing the tape measure through the internal gap or gauging by eye if possible.



**Please Note: Some models will require an adapter to allow the use of AXfix such as a single sided swinging arm or where the OEM axle bolt has no opening or the opening is too narrow.**



**Rear Adapter for the BMW R1250GS shown.**



**Front Adapter for the KTM 1290 Adventure shown.**

**Step 3:**

Send your measurements along with your Make, Model, Manufacture year and Model code (if possible) to [Technical@Scottoiler.com](mailto:Technical@Scottoiler.com) and we can locate the correct AXfix kit for your motorcycle.