

## Additional instructions for Kit 3 and 29



all information from right and left are always given in the direction of travel

To attach the rear AXfix in the direction of travel, proceed as follows:

1. Insert the enclosed adapter into the single-sided swing arm from the right side. The larger diameter must also be partially inserted into the hollow axle (the axle nut spring protrudes slightly into the hole, so it must be lifted slightly).
2. Push the AXfix through the adapter from the right and place the single cone with handle on the left side screw tightly by hand.



- Do not use any tools! - Make sure the cones are centered!

3. Tighten the left tensioning strap first.

When unloading, please proceed in reverse order. First, loosen the right-hand tensioning strap.

**Note:** The single-sided swing arm adapter is designed to have no stop on the left side. Once the straps are attached, the AXfix can no longer move along the axle.

Kit 3 and Kit 29



Image in direction of travel right



Picture in direction of travel left

Additionally with Kit 29

**Front in direction of travel:**

1. Insert the AXfix from the right through the hollow axle.
2. The plastic disc from the left (with the recess facing outwards pointing) onto the AXfix.
3. Then screw the single cone with handle on the left side tightly by hand.



- Do not use any tools! - Make sure the cones are centered!

